
Subject: Re: CB030, A 68030 SBC for hobbyists
Posted by [quarterturn](#) on Sun, 09 Aug 2020 22:17:56 GMT
[View Forum Message](#) <> [Reply to Message](#)

'sleep' seems be the culprit:

Oops: 00000000
Modules linked in:
PC: [<00007326>] fp_normalize_ext+0x0/0xc
SR: 2010 SP: 00cd1f3c a2: 0063f0a0
d0: 0063f494 d1: 00000002 d2: f23c5538 d3: 8002b32c
d4: 8000d8f4 d5: 00000002 a0: 0000000e a1: 0063f438
Process sleep (pid: 122, task=0063f0a0)
Frame format=B ssw=074d isc=0c40 isb=7fff daddr=0000000a dobuf=00cd1fbc
baddr=0000732a dibuf=00000000 ver=f
Stack from 00cd1fc4:
00007ab8 00006956 00000064 8002a818 8002b32c 8000d8f4 00000002 efca1f88
8013efef efca1f86 00000001 ffffffff 00000000 00048011 8668002c
Call Trace: [<00007ab8>] fp_finalrounding+0x6/0x1a
[<00006956>] fpu_emu+0x1e/0x2c
[<00048011>] show_modinfo_srcversion+0x1/0x26
Code: 660a 7001 5188 4e75 e388 67f2 4280 60f4 <2018> 0c40 7fff 677e 2010 6a04 59
88 4e75 660c 2028 0004 6638 4260 5588 4e75 edc0
Segmentation fault

.
Data read fault at 0x0000000a in Super Data (pc=0x7326)
BAD KERNEL BUSERR
Oops: 00000000
Modules linked in:
PC: [<00007326>] fp_normalize_ext+0x0/0xc
SR: 2010 SP: 00e63f3c a2: 0063f0a0
d0: 0063f494 d1: 00000002 d2: f23c5538 d3: 8002b32c
d4: 8000d8f4 d5: 00000002 a0: 0000000e a1: 0063f438
Process sleep (pid: 123, task=0063f0a0)
Frame format=B ssw=074d isc=0c40 isb=7fff daddr=0000000a dobuf=00e63fbc
baddr=0000732a dibuf=00000000 ver=f
Stack from 00e63fc4:
00007ab8 00006956 00000064 8002a818 8002b32c 8000d8f4 00000002 efb05f88
8013efef efb05f86 00000001 ffffffff 00000000 00048011 8668002c
Call Trace: [<00007ab8>] fp_finalrounding+0x6/0x1a
